Report

1. The content of my dataset:

```
Floor 1 = 115 photos
Floor 2 = 64 photos
```

The photo below that show my mIOU in four different way:

a. Foor1 in apartment0 model

```
[Eval Summary]:
Mean IoU: 0.1072, Accuracy: 65.70%
Evaluation Done!
```

b. Foor1 in others model

```
[Eval Summary]:
Mean IoU: 0.0367, Accuracy: 40.86%
Evaluation Done!
```

c. Floor2 in apartment0 model

```
[Eval Summary]:
Mean IoU: 0.0671, Accuracy: 80.61%
Evaluation Done!
```

d. Floor2 in others model

```
[Eval Summary]:
Mean IoU: 0.0594, Accuracy: 58.61%
Evaluation Done!
```

The accuracy and loss that I forgeted to take a screenshot when finished training, so I lost this information. 😥

2. The way that how to run my program can see in the README.

• Add the code below in the <u>load.py</u> to save the image of the annotations

```
# 對語意分割進行截圖(相比HW1所增加的)
instance_id_to_semantic_label_id = np.array(scene_dict["id_to_label"])
semantic = instance_id_to_semantic_label_id[a[3]]
semantic_img = Image.new("L", (semantic.shape[1], semantic.shape[0]))
semantic_img.putdata(semantic.flatten())
semantic_img.save(os.path.join("./my_data/annotations"+str(input_floor)+"/apartment"+str(photo_of_number_change)+".png"))
```

my_trans.py to change the path to .odgt

· Use the code that appy in the hackmd and finetune them to get the custom.odgt

```
# my_trans.py
import os
import cv2
import json
def odgt(img_path):
    seg_path = img_path.replace('images1', 'annotations1')
    seg_path = seg_path.replace('.jpg', '.png') # image 要jpg, annotations 要png
    if os.path.exists(seg_path):
       img = cv2.imread(img_path)
        h, w, _{-} = img.shape
       odgt_dic = {}
        odgt_dic["fpath_img"] = img_path
        odgt_dic["fpath_segm"] = seg_path
       odgt_dic["width"] = h
        odgt_dic["height"] = w
        return odgt_dic
    else:
        return None
save = 'data_for_reconstruct1.odgt'
dir_path = f"./my_data/images1"
img_list = os.listdir(dir_path)
img_list.sort()
print(img_list)
img_list = [os.path.join(dir_path, img) for img in img_list]
with open(f'./my_data/{save}', mode='wt', encoding='utf-8') as myodgt:
    for i, img in enumerate(img_list):
       a_odgt = odgt(img)
       if a_odgt is not None:
            myodgt.write(f'\{json.dumps(a\_odgt)\}\n')
```

Use the data that the data_generator generate to train the model. Put my .odgt path in the custom .config file
and then use <u>train.py</u> to train the model that we set in the config. The model that I use is the encoder of
resnet50dilated and the decoder of ppm_deepsup, the code below is my apartment.yaml

```
# custom .config
DATASET:
 root_dataset: ""
 list_train: "./data/training.odgt"
                                        # generate by trans.py
 list_val: "./data/validation.odgt"
 num_class: 101
 imgSizes: (300, 375, 450, 525, 600)
 imgMaxSize: 1000
 padding_constant: 8
 segm_downsampling_rate: 8
 random_flip: True
MODEL:
 arch_encoder: "resnet50dilated"
 arch_decoder: "ppm_deepsup"
 fc_dim: 2048
TRAIN:
 batch_size_per_gpu: 2
 num epoch: 20
 start_epoch: 0
 epoch_iters: 650
 optim: "SGD"
```

```
lr_encoder: 0.02
lr_decoder: 0.02
lr_pow: 0.9
beta1: 0.9
weight_decay: 1e-4
deep_sup_scale: 0.4
fix_bn: False
workers: 16
disp_iter: 20
seed: 304

VAL:
    visualize: False
    checkpoint: "epoch_20.pth"

TEST:
    checkpoint: "epoch_20.pth"
    result: "./"
DIR: "ckpt/apartment0"
```


mIOU in eval_multipro.py

```
new_iou = []
wb = openpyxl.load_workbook('apartment0_classes.xlsx', data_only=True)
s1 = wb['Sheet1']
for i in range(2,51):
    label = s1.cell(i,1).value
    print("add " + str(int(label)) + " " + str(iou[int(label)]))
    new_iou.append(iou[int(label)])
wb.save('apartment0_classes.xlsx')

print('[Eval Summary]:')
print('[Eval Summary]:')
print('Mean Iol: {:.4f}, Accuracy: {:.2f}%'
    .format(sum(new_iou)/len(new_iou), acc_meter.average()*100))
```

The pictures below is my result of the reconstruction.


a. Foor1 in apartment0 model



b. Foor1 in others model



c. Floor2 in apartment0 model



d. Floor2 in others model

